


SEAT PLATE OPERATING INSTRUCTIONS



TURN CLOCKWISE TO INCREASE TILT TENSION AND COUNTER-CLOCKWISE TO DECREASE.

TO RAISE SEAT HEIGHT, REMOVE PRESSURE FROM THE SEAT AND LIFT LEVER UP.
TO LOWER SEAT HEIGHT, SIT ON THE CHAIR AND LIFT LEVER UP.

TURN THE KNOB CLOCKWISE TO LOCK BACKREST IN POSITION. TO UNLOCK, TURN THE KNOB COUNTER-CLOCKWISE AND LEAN BACK ON THE CHAIR TO RELEASE THE ANTI-KICK BACK MECHANISM.



LIFT LEVER UP TO SLIDE AND RELEASE LEVER ONCE DESIRABLE POSITION IS REACHED.